

Lab 6(i)

Configuring Web Server & DNS using Packet Tracer

- * All domain names have unique IP address. But it is difficult to remember IP addresses. All domain name is mapped with unique IP address.

Steps:-

Configure Server

Services → ~~Default gateway~~ → 10.0.0.1

* Services → DHCP → Services ON

Default gateway :- 10.0.0.1

DNS Server :- 10.0.0.2

TFTP Server :- 10.0.0.2

Save.

* Click PC0 → Desktop → IP configuration → DHCP (Request successful)

* DNS → On → Name: networks.com

Address: 10.0.0.1

Add.

* PC0 → Desktop → Web browser

URL :- 10.0.0.1 Go

URL :- networks.com.

* Configure server:- Settings → Static: Default gateway: 10.0.0.2

Config →

DNS Server: 10.0.0.2

FastEthernet 0 → Static IPv4 address: 10.0.0.2

Subnet mask: 255.0.0.0

Services → HTTP and HTTPS On, DHCP off

DNS → On Name: bmsce.com

Address: 10.0.0.2 Add.

* Configure PC :- ~~Static~~ Config → Static: Default gateway: 10.0.0.2

DNS Server: 10.0.0.2

FastEthernet 0 → 10.0.0.1 (IPv4 address)

Subnet mask: 255.0.0.0

* Click PC → Desktop → Web Browser → URL: 10.0.0.2 → Go

URL: bmsce.com → Go